



SIDE B

Place this edge against the boat hull where the Magnetic Bracket is to attach.

LARGE SHIM



SMALL SHIM

HOW TO USE THIS TEMPLATE:

1. Tear out the template.
2. Align the top edge (SIDE A) to the waterline (must be done with boat out of water)
3. Place SIDE B against the boat where the magnetic bracket should be attached.
4. If the gap between SIDE C and the boat is greater than 1 inch, cut the Large Shim on the dotted lines. Side C should be as close to hull without touching the hull. The shim needed should be the largest size remaining on the template after cutting off the sections that are too large.

SIDE A

Align this edge with the waterline

SIDE C

This edge should be as close to the boat hull as possible without touching.